

Pour and Roll Products.

An extensive range of waterproofing products manufactured using selected re-enforcements coated with oxidized and modified bitumens.

Our suggested 3 layer built up specification offering 20 year product guarantee:

- a. Plywood deck to BS
- b. (Vapour control layer) Chesterstop VB (product code P714) (metal lined)
- c. Insulation (PUR) type rigid board
- d. BS747 type 3G venting Chesterplus 3G (product code P351)
- e. Intermediate layer Chestermeric 250 Sand (product code P615) BBA – No 9413062
- f. Final waterproofing layer Chestermeric 350 mineral finish (product code P621) BBA – no 9413062

Chesterfelt recommend that all products must be laid in accordance with BS8217 Code of Practice for built up felt roofing.

The above system would comply with fire rating designation type AA.



Chestermeric High Performance SBS



Description The classic three layer built-up system using universal BS747 type 3G venting layers with polyester re-enforced intermediate layers and final waterproofing layer in plain finish of mineral granules. Offering 20 year system guarantees.

[Download BBA Certificate No. BBA 94/3062](#)

Code	Description	Width	Roll Length	Finish	Pallet Quantity	Roll Weight
P613	Chestermeric 180	1.0m	20m	Sand	25	36kg
P615	Chestermeric 250	1.0m	16m	Sand	25	40kg
P620	Chestermeric 250	1.0m	8m	Green Mineral	25	30kg
P621	Chestermeric 350	1.0m	8m	Green Mineral	25	38kg

Chesterflex High Performance Systems



Description A traditional range using High performance polyester bases manufactured to BS747, when used in a three layer system with suitable preparation layer 10 year product guarantees are available.

[Download BBA Certificate No. BBA 94/3062](#)

Code	Description	Width	Roll Length	Finish	Pallet Quantity	Roll Weight
P511	Chesterflex 125	1.0m	16m	Sand	30	29kg
P516	Chesterflex 350	1.0m	8m	Sand	25	34kg
P521	Chesterflex 350	1.0m	8m	Green Mineral	25	38kg
P513	Chesterflex 180	1.0m	20m	Sand	25	38kg

MATERIAL SAFETY DATA SHEET

**For: CHESTERFELT POUR & ROLL FELT
CHESTERFELT SHEDFELT
CHESTERFELT TORCH ON FELT**

HEALTH & SAFETY REFERENCES:

Health and Safety at Work Act 1978
COSHH Regulations
Code of Practice for Safe Handling of Hot Bitumen for Roofing Purposes
Booklet 6B Health and Safety Construction Work Roofing

GENERAL

Health and Safety must be considered before site work commences during the design and construction stages. This is necessary for the safety of operatives; site inspectors and any other concerned with the progress of work on the site.

The working environment needs to comply with all relevant Health and Safety at Work, COSHH data and the requirements of the local Factory Inspectorate.

PRIOR TO COMMENCEMENT OF WORK

1. Operatives must be made aware of their responsibilities for their own safety and the safety of others.
2. Requirements for storage arrangements for reasons of Health and Safety along with scaffolding, hoisting arrangements should be made in advance of commencement of work.
3. Restrictions on work, where hot materials such as bitumen and the use of naked flame, may present considerable risk to people and the fabric of the building. This must be taken into account as the application of roofing materials can involve unsafe practice and if basic safety requirements are not followed it can lead to serious injury and incidents which may be reported immediately to the site supervisor.
4. Adequate safety guards and guarded landing platforms should be in place before work commences. The area immediately below any hoist or roof work should be guarded in order to prevent operatives standing directly below.
5. Roof perimeter scaffolds require gangways of correct minimum width with a guard and guarded landing platforms should also be in place before work commences.
6. The roof area must be cleared of all materials other than those being used, unless this cannot be reasonably avoided.
7. All rolls, machinery etc. must be stored in a safe place when not in use and special care should be taken to ensure all electrical supplies are immobilised when not in use. Maintenance of tools etc. is essential for good working practice.
8. Preparations should be made for any changes of weather conditions. Precautions such as temporary roofs, and sheet covering including temporary drainage should be arranged in advance.

USE OF HOT BITUMEN

During the application and preparation of hot bitumen particular safety issues arise:

1. Care is necessary in the placing and setting up of the boiler and controlling of the gas heating supply.
2. Where bitumen is heated at a lower level and then hoisted to the roof it must be kept clear or scaffolding and the area beneath guarded to restrict movement below the hoist.
3. The manufacturers instructions for the safe use of boilers should be followed at all times.
4. Particular attention should be paid to the temperatures of the boiling bitumen, which should not exceed by 250°C or the flash point less 15°C.
5. When in use the boiler must be constantly attended by a responsible person and appropriate fire-fighting equipment should always be close to hand.
6. Boilers containing hot bitumen should not be lowered or transported.

HANDLING AND STORAGE

1. Requirements for storage arising from Health and Safety reason should be considered and advice sort from the appropriate manufacturers.
2. All materials should always be checked upon delivery and prior instructions given as to accessibility to site etc. The manufacturer's name and batch number should identify them. All materials should arrive on site unopened in their original wrappers.
3. Rolls of material should always be transported and stored in an upright position on a clean weatherproof base and protected against the weather.
4. Drums containing liquids should be checked for spillage and if stored over a long period of time rotated to prevent a long breaking of emulsions.
5. Pebbles and chippings should be delivered in bags and stored on a clean base.
6. Storage locations and loadings should be agreed before the commencement of work.
7. All roofing felts are relatively heavy; care must be taken when lifting.

CONCLUSION

The Contractors and all operatives should comply with all safety directives whilst on site. Protective clothing and helmets should be worn at all times.

It is essential for full co-operation to be established by all concerned both prior to commencement of site work and throughout its duration.